

# ULTIMATE- 412-U and 416-U IN-COUNTER DISPENSER INSTALLATION

TAKE-A-TICKET, INC. RECOMMENDS YOU HAVE A PROFESSIONAL CONTRACTOR INSTALL THIS UNIT. HERE ARE SOME SUGGESTIONS IF YOU CHOOSE TO DO IT YOURSELF.

Note: You may want to remove the loose top glass that is taped in before starting. The bottom glass is sealed in place to prevent leaking below the counter.

## #5 STEPS FOR INSTALLATION:

### 1. CHECK CLEARANCE UNDER THE COUNTER BEFORE YOU CUT THE HOLE!

- The hole is 18-3/4" (clerk to customer) x 18-3/4". Depth is about 15" from the counter top to bottom of unit.
- Setback from the clerk's side is at least 4" so clerks do not bump into the unit.
- CHECK THE CLEARANCE AGAIN BEFORE YOU CUT THE HOLE!!! NOW CHECK IT AGAIN!!

### 2. SEPARATE THE UPPER AND LOWER PARTS OF THE DISPENSER.

Do not lose the bolts, nuts, and washers. Set the drawers and base aside until upper part of unit (the portion with the glass) is installed in the counter.

### 3. CUT THE HOLE. WAIT!!! ARE YOU SURE ABOUT THE LOCATION???

- Cut the hole to the specifications in step 1 above.
- Place a bead of caulking around the hole on the counter surface.
- Drop the upper portion of the dispenser (metal frame and glass) into the hole. The open side of the plastic faces the clerk.

### 4. REATTACH THE BASE TO THE UPPER PORTION OF THE DISPENSER.

Adjust height as necessary when bolting the base to the upper part of the dispenser. Use the plastic spacer block taped to these instructions. Place block up to the lowest point on the metal frame and raise base up to the block as a starting point for the height.

### 5. LOAD THE DRAWERS AND PLACE THEM IN THE BASE.

QUESTIONS? Call us at (800) 253-4295 or email: [info@tatinc.com](mailto:info@tatinc.com)